

Assembly Instructions for Kali-Ko Holiday Inn #K626



Inventory: The Kali-Ko Holiday Inn #K626 consists of (6) #C72 72” high panels (with fold down clips attached), (2) #CTD72 72” high triple doors (3) #F26 floors (3) #24D divider panels, (1) #C72C lid (top) (24) #250 floor divider clips (18) #175 door clips (48) #200 panel clips (32) #FDC fold down clips (12) #KHI wall clips (to connect to the divider panels). *Note*: Please make sure your inventory is complete.*

Step 1: All the floors come marked with a label showing the “short side” of the floor. All floors will be installed with the flat side down and with the “short side” label on the right. This will allow the divider panels to be installed on the left side of the floor’s middle divider bar (the divider panels will be centered this way)*.

Step 2: Unwrap the sections of the panels and place in the shape of a 2’x6’ area, making sure that both triple doors are in front, on either side of a regular #C72 72” panel. Do not connect the #200 panel clips to the last door and the center panel yet ...you will need access to place the floors inside the unit. Next, place the #F26 bottom floor (short side to the right) inside the 2’x6’ area and connect the floor and panel by snapping on (2) #250 floor divider clips, attaching each near the ends of the panel to the floor (See figure 1).

Step 3: Take a #24D divider panel and place on the left side of the floor’s middle bar. The flat side of the #24D divider panel will go against the floor’s middle bar. Next, attach (2) #KHI wall clamps to the #24D divider panel and outer enclosure panel (See figure 2-looking from the inside). Place (2) #HI wall clamps on the other side of the enclosure.

Step 4: The enclosure comes with #FDC fold down clips attached on the inside panels. Fold down these clips so that they are flat and place the second floor inside the enclosure, on top of the divider panel. Next, attach the #250 floor divider clips and panel divider as shown in the previous steps.

Step 5: Place the #F24 last floor in and the #24D last divider and secure as shown in the previous steps.

Step 6: Attach the #C72C lid on top, making sure the #200 panel clips are facing down.

Congratulation! You are now ready to use your Kal-Ko Holiday Inn #K626 enclosure.

Fig. 1



Fig. 2



**Note-divider panels may be removed later and re-arranged according to desired configurations of Holiday Inn.*

Property of Kali-Ko Kathouses, Div. of Rover Company



WWW.ROVERPET.COM