

Stacking Instructions for Kali-Ko Kathouses

Place the #S31 support frame in the inside-top perimeter of the enclosure, making sure it is flush with the side pipe edges. Snap (2) #250 floor divider clips, from the underside of the panels, to the floor support (between the 2nd bar from either side of the panels – See *figure 1*). On the door panels (inside the door area) connect a #250 floor divider clip on either side of the upper door opening to the support frame.

Place the floor on top of the unit. The pipe side should be up. Let the floor rest on the #S31 support frame, and take the other panel section(s) and place it on top of the unit, making sure it is flush with both floor and lower section. Snap a #250 floor divider clip to the bottom pen, connecting it to the upper pen (See *figure 2 below*.) For the door section there should have a #250 floor divider clip placed on the handle side of the bottom door opening to the door frame beneath it. *NOTE: This is to the outside frame of the lower section (see figure 3 below)*. Next, snap (2) #250 floor divider clip from each panel of the frame below it to the floor section. Connect the remaining enclosure section to the floor as shown in the previous steps, and repeat procedure for both sides.

Fig. 1



Fig. 2



Fig. 3



Property of Kali-Ko Kathouse, Div. of Rover Company

www.roverpet.com

