

Assembly Instructions Urine Splash Guard for #USG7

Inventory: The Kali-Ko Urine Splash Guards comes with (1) #USG7 flat stock of PVC (2) #USG7C holder clips

Step 1: The clip holder is “snapped” onto one of the vertical bars of the panel with the clip holder slit in the down position. The vertical bar used must be at least 3 bars in toward the center of the panel, so that the guard will flex enough to fit in the slit. The Urine Splash Guard must be used in the center of the panel.

Step2: If your enclosure has a door panel it should be unattached from the enclosure and turned upside down and re attached to the enclosure to clear the urine splash guard.

Property of Kali-Ko Kathouse, Div. of Rover Company

www.roverpet.com

